



DEFENDER SERIES SCALES


Base Mount Assembly Instructions

(Refer to Documentation CD for operating instructions)

Defender Series models may differ slightly from the illustration

1


Unpack



3

Install Base Mount
Use correct hardware



Models DxxxRx:



2

Install Base Mount
Use correct hardware


Models DxxxHx, DxxxQx, DxxxWx:




4

Install cable clamp as shown
Route load cell cable

Models DxxxHx, DxxxQx, DxxxWx:



Models DxxxRx:



Continued
See other side





DEFENDER SERIES SCALES

Base Mount Assembly Instructions


5

Reverse the Indicator Top Cover
(For instructions refer to User Manual)



7


Install Indicator
Secure cable with tie-wrap as necessary



Note: Ensure cables
do not interfere with Platform.



6

Connect Load Cell
Connector to Indicator



8

Complete the scale set-up. Follow the
Assembly Instructions included with your Scale



Note: ensure cables
do not interfere with Platform.



* 8 0 2 5 1 4 2 0 *

P/N 80251420 A © Ohaus Corporation 2008, all rights reserved.

Printed in China