

The Male to Female RS-232 interface cable is used to connect the balance or weighing scale to other devices such as the ATP Thermal Printer or simply to a computer. Data collection is streamlined and you no longer have to input the readings manually



Manufacture: Adam
Equipment
SKU: **3014011014**
Weight: 2.00 lb

Please Call
(800)832-0055

Features

The Male to Female RS-232 interface cable is used to connect the balance or weighing scale to other devices such as the ATP Thermal Printer or simply to a computer. Data collection is streamlined and you no longer have to input the readings manually

i81u812

[Contact US](#)

[718-336-5900](#)

[Returns](#)

[Store Policies](#)

[About Us](#)

- Phone: [\(800\)832-0055](#) or [\(718\)336-5900](#)
- Chat with us via [WhatsApp Chat](#)
- Address: 4802 Glenwood Rd. Brooklyn, NY 11234
- © 2000 - 2020 scalesgalore.com (a division of Itin Scale Co., Inc.) All rights reserved.