




## Mark-10 SF021 Preload / sample touch

Stops the crosshead and/or zeroes the travel display at an initial preload - useful in tensile, compression, spring, elongation, and other applications. Preload is programmable as a percentage of force gauge/load cell full scale. Three modes: (1) stop, (2) stop and zero, and (3) zero without stopping.



**MARK-10®**

**Manufature:** Mark 10

**SKU:** SF021

**Weight:** 2.00 lb

Free Ground Shipping within the  
48 continental US States

**Please Call**  
**(800)832-0055**

### Features

Stops the crosshead and/or zeroes the travel display at an initial preload - useful in tensile, compression, spring, elongation, and other applications. Preload is programmable as a percentage of force gauge/load cell full scale. Three modes: (1) stop, (2) stop and zero, and (3) zero without stopping. Requirements - SF009 travel indication Series 7 or 5 gauge or indicator

i81u812

Contact US

718-336-5900

Returns

Store Policies

About Us

- Phone: [\(800\)832-0055](tel:(800)832-0055) or [\(718\)336-5900](tel:(718)336-5900)

- Chat with us via [WhatsApp Chat](#)

- Address: 4802 Glenwood Rd. Brooklyn, NY 11234

- © 2000 - 2024 scalesgalore.com (a division of Itin Scale Co., Inc.) All rights reserved.